

Installation Instructions

Seip 24 volt receiver upgrade kit type EKR1MCGEF



Seip EKR1MCGEF receiver kit (shown with mini & midi keyfob)

Compatibility

Suitable for use with remote controlled garage door and gate operators with a 24 volt power source for ancillary equipment. The Seip EKR1MCGEF receiver is compatible with the HomeLink in-car remote system as fitted to Audi, Bentley, BMW, Chrysler, Jaguar, Lamborghini, Maybach, Mercedes-Benz, Opel, Porsche, Tesla, VW & Vauxhall (car must have Homelink system with software rev. 6 or later)

Power Requirement

operating voltage range: 16 - 30 volts AC or 18 - 34 volts DC
nominal standby consumption < 5mA

Connections

Red wire: AC or DC power source (see above)
Black & Blue wires: common (ground)
Blue wire: Volt free relay contact for direct connection to the 'impulse' control circuit of a gate or garage door operator. (max load 0.5A)

Positioning

The receiver unit should be secured in a dry position using the self-adhesive pads supplied. If used with gate equipment it must be housed in a weatherproof enclosure as the receiver is not water resistant. (if installed inside a steel cabinet an external aerial will be required)

433Mhz MPT 1340 UK approved frequency

Digital code system

The keyfob transmitters communicate to the receiver by digitally coded transmission. Each transmitter is factory pre-programmed with a unique set of security codes from a choice of 260 million different codes and 'hops' to a new code after every operation. The receiver can learn & memorize the unique security code signature of up to 25 Seip SKR series keyfob transmitters.

Programming instructions

Your receiver will be pre-programmed ready for use with the key-fob(s) supplied with it, but if any further key-fobs are added these will require programming as follows:

1/ Hold the new keyfob transmitter against the receiver casing beside the antenna and press the button you wish to use until the red light shows. (the 24v power must be connected)

2/ Take the keyfob away from the receiver & press the same button again until the red light goes out.

The new fob should now operate your receiver.
Repeat the above procedure for up to 25 Seip SKR series keyfobs.

Clearing the memory

(necessary if a key-fob has been lost or stolen)

Take any pre-programmed keyfob transmitter and hold it against the receiver casing beside the antenna and press and hold the programmed button for about ten seconds until the red light goes out. This will erase all previously memorised fobs, follow the programming instructions above to re-teach your keyfobs

Battery Replacement

Mini type Key-Fob - Remove the screw from rear casing and prize the two halves of the casing apart to reveal two **CR1616** 'coin' type batteries

Midi type Key-Fob - Slide open the battery door to reveal a type CR2032 coin type battery.



Seip 24 volt single channel radio control receiver - model EKR1MCGEF

Range - up to 100Mtrs

Electrical connections for use with popular UK garage door operators

The Seip receiver unit is supplied with coloured wires, connect these wires to your garage door opener unit as follows:

Make of door operator	Black & blue wires (common)	Blue wire (relay contact)	Red wire (24 volt power)
Garamatic GD100 (with orange or green three pin receiver plug)	Remove BLUE wire from the original orange or green receiver plug & connect BLACK & BLUE wires from new receiver to this terminal	Remove YELLOW/GREEN wire from the original orange or green receiver plug & connect BLUE wire from new receiver to this terminal	Remove BROWN wire from the original orange or green receiver plug & connect RED wire from new receiver to this terminal
Marantec 'comfort' series	Connect BLACK & BLUE wires from Seip receiver to terminal 1	Connect BLUE wire from Seip receiver to terminal 2	Connect RED wire from Seip receiver to terminal 3
Hormann SupraMatic E, Promatic, Garador Auto Expert & M2	Remove the original green wire from terminal 20 (common) and connect the new black & blue wires	Remove the original white wire from terminal 21 (impulse signal) and connect the new blue wire	Remove the original brown wire from terminal 5 (24v DC supply) and connect the new red wire
Hormann Ecomatic	Remove the original green wire from terminal 1 (common) and connect the new black & blue wires	Remove the original white wire from terminal 2 (impulse signal) and connect the new blue wire	Remove the original brown wire from terminal 3 (24v DC supply) and connect the new red wire

Note: For best range the antenna (rigid black wire) should be positioned away from any metalwork or wires

Amourelle Products, Unit 16 James Scott Rd, Halesowen,
West Midlands B63 2QT - Phone: 01384 900 264

Further information can be found on our website: www.garage-door-remotes.co.uk/seip-ts433-fit.htm